



**2003-09 FJR1300**

**Install 24mm ID washer on top of cartridge. Washer must locate on shoulder (install RT spring and turn this will help to locate washer). Spring must be installed with small tapered end down. Install 21mm ID washer and stock washer on top of spring. Next install preload spacer tube. (RT spring is longer than stock-check preload instruction setup for proper setup.) Install nut then install fork cap.**

<IPFRSPS4032FJRWASHERWARNING.doc>