

Rebuilding a Shock Seal Head



Hold in a vise. TMVJ 065 preferred



Pull off Top-out Spring (if present)



Pry out Top-out Bumper



Remove Spacer and Top-out Spring Holder (sometimes just a Washer)



Remove Shock Seal and Washer (if present)



Flip Seal Head. Pry off Dust Seal



Insert TSBD with step-side towards Bushing



Press out Bushing with the Vise



Bushing out, clean Seal Head Body

